

αiS series (200V)

A06B-□□□□-B△○▽#◎◎◎◎

Symbol in specification no Servo motor name	□□□□	△						○						▽			◎◎◎◎	
		0	1	2	3	4	5	0	1	2	3	4	5	0	1	2	0000	0100
αiS 2/5000	0212	○	○	○	○	○	○	○	-	-	-	-	-	○	○	○	○	○
αiS 2/6000	0218	○	○	○	○	○	○	○	-	-	-	-	-	○	○	○	○	○
αiS 4/5000	0215	○	○	○	○	○	○	○	-	-	-	-	-	○	○	○	○	○
αiS 4/6000	0210	○	○	○	○	○	○	○	-	-	-	-	-	○	○	○	○	○
αiS 8/4000	0235	○	○	○	○	○	○	○	-	-	-	-	-	○	○	○	○	○
αiS 8/6000	0232	○	○	○	○	○	○	○	-	-	-	-	-	○	○	○	○	○
αiS 12/4000	0238	○	○	○	○	○	○	○	-	-	-	-	-	○	○	○	○	○
αiS 12/6000	0230	○	○	○	○	○	○	○	-	-	-	-	-	○	○	○	○	○
αiS 22/4000	0265	○	○	○	○	○	○	○	-	-	-	-	-	○	○	○	○	○
αiS 22/6000	0262	○	○	○	○	○	○	○	-	-	-	-	-	○	○	○	○	○
αiS 30/4000	0268	○	○	○	○	○	○	○	-	-	-	-	-	○	○	○	○	○
αiS 40/4000	0272	○	○	○	○	○	○	○	-	-	-	-	-	○	○	○	○	○
		-	-	-	○	○	○	-	-	○	-	-	-	○	○	○	○	○
αiS 50/2000	0042	○	○	-	-	-	-	○	-	-	-	-	-	○	○	○	○	○
		-	-	-	○	○	-	-	-	○	-	-	-	○	○	○	○	○
αiS 60/2000	0044	○	○	-	-	-	-	○	-	-	-	-	-	○	○	○	○	○
		-	-	-	○	○	-	-	-	○	-	-	-	○	○	○	○	○
αiS 50/3000 with fan	0275	○	○	-	○	○	-	-	○	-	-	-	-	○	○	○	○	-
		-	-	-	○	○	-	-	-	-	○	-	-	○	○	○	○	-
αiS 60/3000 with fan	0278	○	○	-	-	-	-	-	○	-	-	-	-	○	○	○	○	-
		-	-	-	○	○	-	-	-	-	○	-	-	○	○	○	○	-
αiS 100/2500	0285	○	-	-	○	-	-	○	-	-	-	-	-	○	-	-	○	○
αiS 100/2500 with fan	0285	○	-	-	○	-	-	-	○	-	-	-	-	○	-	-	○	-
αiS 200/2500	0288	○	-	-	○	-	-	○	-	-	-	-	-	○	-	-	○	○
αiS 200/2500 with fan	0288	○	-	-	○	-	-	-	○	-	-	-	-	○	-	-	○	-
αiS 300/2000	0292	○	-	-	-	-	-	-	○	-	-	-	-	○	-	-	○	-
αiS 500/2000	0295	○	-	-	-	-	-	-	○	-	-	-	-	○	-	-	○	-

* When $\odot\odot\odot\odot$ is #0000, omit the specification of $\odot\odot\odot\odot$.

* Specify $\triangle = 3$ to 5 in the case of $\circ = 2$ or 3.