

αiS series (400V)

A06B-□□□□-B△○▽#◎◎◎◎

Symbol in specification no Servo motor name	□□□□	△						○						▽			◎◎◎◎	
		0	1	2	3	4	5	0	1	2	3	4	5	0	1	2	0000	0100
αiS 2/5000 HV	0213	○	○	○	○	○	○	○	-	-	-	-	-	○	○	○	○	○
αiS 2/6000 HV	0219	○	○	○	○	○	○	○	-	-	-	-	-	○	○	○	○	○
αiS 4/5000 HV	0216	○	○	○	○	○	○	○	-	-	-	-	-	○	○	○	○	○
αiS 4/6000 HV	0214	○	○	○	○	○	○	○	-	-	-	-	-	○	○	○	○	○
αiS 8/4000 HV	0236	○	○	○	○	○	○	○	-	-	-	-	-	○	○	○	○	○
αiS 8/6000 HV	0233	○	○	○	○	○	○	○	-	-	-	-	-	○	○	○	○	○
αiS 12/4000 HV	0239	○	○	○	○	○	○	○	-	-	-	-	-	○	○	○	○	○
αiS 12/6000 HV	0237	○	○	○	○	○	○	○	-	-	-	-	-	○	○	○	○	○
αiS 22/4000 HV	0266	○	○	○	○	○	○	○	-	-	-	-	-	○	○	○	○	○
αiS 22/6000 HV	0263	○	○	○	○	○	○	○	-	-	-	-	-	○	○	○	○	○
αiS 30/4000 HV	0269	○	○	○	○	○	○	○	-	-	-	-	-	○	○	○	○	○
αiS 40/4000 HV	0273	○	○	○	○	○	○	○	-	-	-	-	-	○	○	○	○	○
		-	-	-	○	○	○	-	-	○	-	-	-	○	○	○	○	○
αiS 50/2000 HV	0043	○	○	-	-	-	-	○	-	-	-	-	-	○	○	○	○	○
		-	-	-	○	○	-	-	-	○	-	-	-	○	○	○	○	○
αiS 60/2000 HV	0045	○	○	-	-	-	-	○	-	-	-	-	-	○	○	○	○	○
		-	-	-	○	○	-	-	-	○	-	-	-	○	○	○	○	○
αiS 50/3000 HV with fan	0276	○	○	-	○	○	-	-	○	-	-	-	-	○	○	○	○	-
		-	-	-	○	○	-	-	-	-	○	-	-	○	○	○	○	-
αiS 60/3000 HV with fan	0279	○	○	-	-	-	-	-	○	-	-	-	-	○	○	○	○	-
		-	-	-	○	○	-	-	-	-	○	-	-	○	○	○	○	-
αiS 100/2500 HV	0286	○	-	-	○	-	-	○	-	-	-	-	-	○	-	-	○	○
αiS 100/2500 HV with fan	0286	○	-	-	○	-	-	-	○	-	-	-	-	○	-	-	○	-
αiS 200/2500 HV	0289	○	-	-	○	-	-	○	-	-	-	-	-	○	-	-	○	○
αiS 200/2500 HV with fan	0289	○	-	-	○	-	-	-	○	-	-	-	-	○	-	-	○	-
αiS 300/2000 HV	0293	○	-	-	-	-	-	-	○	-	-	-	-	○	-	-	○	-
αiS 500/2000 HV	0296	○	-	-	-	-	-	-	○	-	-	-	-	○	-	-	○	-
αiS 500/3000 HV	0297	○	-	-	-	-	-	-	○	-	-	-	-	○	-	-	○	-
αiS 100/2000 HV	0098	○	-	-	-	-	-	-	○	-	-	-	-	○	-	-	○	-
αiS 1000/3000 HV	0099	○	-	-	-	-	-	-	-	-	-	-	○	○	-	-	○	-
αiS 2000/2000 HV	0091	○	-	-	-	-	-	-	-	-	-	○	-	○	-	-	○	-
αiS 3000/2000 HV	0092	○	-	-	-	-	-	-	-	-	-	○	-	○	-	-	○	-

- * When $\odot\odot\odot\odot$ is #0000, omit the specification of $\odot\odot\odot\odot$.
- * Specify $\triangle = 3$ to 5 in the case of $\bigcirc = 2$ or 3